

## OFFSET FINGERS - ADHERE TO EXISTING VAPOR BARRIER

BARRIER **EXISTING THERMAL** BARRIER OR CONCRETE EXISTING METAL DECK **EXISTING FIREPROOFING** 

**EXISTING VAPOR** 

EXISTING INSULATION ASSEMBLY -REMOVE AT PENETRATION WITHOUT DAMAGING EXISTING VAPOR BARRIER

**EXISTING EPDM MEMBRANE -**CLEAN & PRIME AT TIE-IN AREA

COVER TAPE

EXISTING FILTER FABRIC