



KEY NOTE:

- ① CORE DRILL TWO HOLES TO PROVIDE "SEAT" FOR FLOOR DRAIN BODY.

NOTES:

1. USE ROUND FLOOR DRAIN ASSEMBLIES. CORE DRILL FOR SLAB PENETRATIONS. CHIPPING, BUSH-HAMMERING OR JACK-HAMMERING OF CONCRETE FLOOR SLAB IS NOT ALLOWED.
2. AFTER PENETRATION IS COMPLETE, REPAIR FIRE PROOFING AT UNDERSIDE OF METAL FLOOR DECK.
3. FLOOR SINKS AT OTHER FLOOR FINISHES AND SUB FLOORING SIMILAR.
4. FLOOR DRAIN BODIES OR FLASHING COLLARS WITH SEEPAGE HOLES ARE NOT ALLOWED.

2221 FLOOR DRAIN - COMPOSITE FLOOR - METALLIC PIPE
SCALE: NTS