



NOTES:

1. FOR USE WITH PVDF PIPE ONLY.
2. USE ROUND FLOOR SINK ASSEMBLIES. CORE DRILL FOR SLAB PENETRATIONS. CHIPPING, BUSH-HAMMERING OR JACK-HAMMERING OF CONCRETE FLOOR SLAB IS NOT ALLOWED.
3. AFTER PENETRATION IS COMPLETE, REPAIR FIRE PROOFING AT UNDERSIDE OF METAL FLOOR DECK.
4. FLOOR SINKS AT OTHER FLOOR FINISHES AND SUB FLOORING SIMILAR
5. FLOOR SINK BODIES WITH SEEPAGE HOLES ARE NOT ALLOWED.

KEY NOTES:

- ① 1/4" DIAMETER BY MINIMUM 1-1/2" LONG EXPANSION BOLT WITH NUTS AND MINIMUM 1-1/4" DIAMETER FENDER WASHER. ALL HARDWARE SHALL BE STAINLESS STEEL.
- ② INTUMESCENT PIPE SLEEVE: 3M ULTRA PPD. SIZE TO MATCH PIPE. INSTALL PER MANUFACTURERS RECOMMENDATIONS. INSTALL ON A FLAT SURFACE ONLY. USE BOLTED CONNECTION ONLY, INSTALL BOLTS AT ALL BOLT CONNECTION POINTS. SEE SECTION 078400, FIRE STOPPING.
- ③ FILL ANY VOIDS BETWEEN DECK AND INTUMESCENT SLEEVE PROVIDE MINIMUM 1/4" BEAD AROUND THE INTUMESCENT SLEEVE
- ④ CORE DRILL TWO HOLES TO PROVIDE "SEAT" FOR FLOOR SINK BODY