


6" WASTE INLET

1/2" IHW CONNECTION FOR RINSE VALVE

3" VENT (2)


2" PIPE CONNECTION FOR LEVEL TRANSMITTER (4) - SELECT LOCATION TO INSURE CLEARANCE ABOVE FOR TRANSMITTER REMOVAL.

MAINTAIN CLEARANCE IN FRONT OF ACCESS MANWAY



10" WASTE OUTLET HEIGHT

SUPPORT STAND WITH ANCHOR PLATE. FURNISHED WITH TANK



2252

VACUUM WASTE COLLECTION TANK ASSEMBLY

SCALE: NTS