




## SWITCH AND SENSOR SYMBOLS:

<u>PREFERRED SYMBOL</u>	<u>DESCRIPTION</u>
\$	SWITCH - SINGLE POLE
\$ <sub>2</sub>	SWITCH - DOUBLE POLE
\$ <sub>3</sub>	SWITCH - THREE WAY
\$ <sub>4</sub>	SWITCH - FOUR WAY
\$ <sub>a</sub>	SWITCH - CONTROL
\$ <sub>CB</sub>	SWITCH - CIRCUIT BREAK
\$ <sub>DT</sub>	SWITCH - SINGLE POLE/DOUBLE THROW
\$ <sub>G</sub>	SWITCH - GLOW TOGGLE
\$ <sub>H</sub>	SWITCH - HORIZONTAL
\$ <sub>K</sub>	SWITCH - KEY OPERATED
\$ <sub>KP</sub>	SWITCH - KEY OPERATED WITH PILOT LIGHT
\$ <sub>LV</sub>	SWITCH - LOW VOLTAGE
\$ <sub>LM</sub>	SWITCH - LOW VOLTAGE MASTER SWITCH
\$ <sub>MC</sub>	SWITCH - MOMENTARY CONTACT
\$ <sub>P</sub>	SWITCH - PILOT LIGHT
\$ <sub>T</sub>	SWITCH - TIMER
\$ <sub>WP</sub>	SWITCH - SINGLE POLE WEATHERPROOF
	SWITCH - DIMMER
	SWITCH - OCCUPANCY SENSOR WALL MOUNTED
	SWITCH - OCCUPANCY SENSOR CEILING MOUNTED