



2602 METERING - DISTRIBUTION PANEL
SCALE: NTS

- NOTES:**
1. TENANT SHALL COORDINATE WITH THE PORT FOR THE CONNECTION TO THE DISTRIBUTION PANEL, AND WHICH BREAKER LOCATION TO USE.
 2. ITEMS SHOWN AS SCREENED BACK LINES ARE EXISTING.

KEY NOTES:

1. EXISTING, DIN RAIL WITH FIVE SETS OF 3 PHASE & NEUTRAL FUSE BLOCKS AND 1/2 AMP SLOW BLOW FUSES, IN NEMA 1 ENCLOSURE. BUSSMANN CH SERIES OR EQUAL.
2. EXISTING, 3/4" C, 4#12, 1#12G AND CONNECT TO 20/3 BREAKER IN SERVICE PANEL.
3. EXISTING, 4x4 GUTTER WITH HINGED COVER.
4. EXISTING, 3/4" CONDUIT. CENTER CONDUIT ON EACH 3 POLE SPACE IN SERVICE PANEL AND TERMINATE IN GUTTER FOR FUTURE TENANT METER WIRING.
5. BY TENANT: PROVIDE METER, WITH CTS AND CONNECTIONS TO THE FUSE BLOCK FOR METER POWER.
6. BY TENANT: PROVIDE A FLEX CONDUIT CONNECTION TO THE METERING COMPARTMENT.
7. TENANT SPACE CIRCUIT BREAKER AND METER SHALL LINE UP HORIZONTALLY, TYPICAL.
8. EXISTING, 2" CONDUIT ROUTED TO RESPECTIVE RETAIL SPACES.
9. BY TENANT: PROVIDE J-BOX FOR FUTURE METERING SYSTEM CONNECTION POINT.
10. BY TENANT: PROVIDE DATA CONDUIT, 2/C #18 SH CABLE AND CONNECTION TO THE TERMINAL REVENUE METERING SYSTEM.
11. BY TENANT: PROVIDE CIRCUIT BREAKER, AND SERVICE CONDUCTORS TO LEASE SPACE.